

ASSEMBLY INSTRUCTIONS

Carefully unpack this lamp and place it on a flat surface.

1. Attach base (3) and metal washer (2) onto pole (4) and secure them together with nut (1) with tool (Included).
2. Connect the junction box (5) together. Connect pole (4) and pole (7) together. Secure with screw (6) with screwdriver (Not included).
3. Attach the shade (9) onto socket (8) and secure it with socket ring (10).
4. Install the bulb (11) into socket (8).

Use 3 pcs 60W (Maximum) Incandescent A Type bulb or 13W CFL Type bulb.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as safety a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

ATTENTION:

POUR PRÉVENIR LES CHOCS ÉLECTRIQUES NE PAS UTILISER CETTE FICHE POLARISÉE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ÊTRE INSÉRÉES A FOND SANS EN LAISSER AUCUNE PARTIE À DÉCOUVERT.

※ PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.

※ SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

