ASSEMBLY INSTRUCTION

STEP1:INSERT(1)INTO THE HOLE IN THE DECK
STEP2:HOOK SHROUDS TO THE PLACES(2),(3),(4) (5),(6)AND(7) RESPECTIVELY.

