



**For ease of assembly start with an open space preferably with carpet or smooth surfaces to avoid accidental scratching**

Assembly time: 10-15 minutes

**The power cable can be pulled through the bottom of the base to ensure a snug fit, this will also pull all the pieces into alignment throughout the assembly process.**

1. Screw the separate strut to the main body and then the wired strut to the other side.

**TAKE CARE NOT TO SCRATCH THE BASE WITH THE STRUT ENDS**

2. carefully align the strut ends through the antitwist bracket and slot them into the holes in the base and the base weight and then tighten the nut and washer at the base with the spanner provided.

**PLEASE CHECK THAT BOTH NUTS ARE FIRM TO PREVENT TWIST. THE SPANNER IS ANGLED TO HELP YOU TIGHTEN THEM EFFECTIVELY**

3. Align the top and ensure the arms slot into the side nuts securely before securing with the grub screws

4. Remove the shade washer from the flexi arm and fit the glass - carefully tighten the shade washer with the tool provided

5. Fit the bulbs - E27/ES Large screw in bulb for the top upright and the E14/SES narrow screw in bulb for the flexi arm 'child' lamp