



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. Install the column (D) onto the fixed body (F) and secure with the screw (E).
4. Assemble the rods (C) together and thread the bottom end into the coupling on column (D) until snug. Thread the top end of the rods into canopy (A).
5. Install the shade (H) onto the socket (G) and secure with the spacer (J) and socket ring (I).
6. Install the bulb (not included) into the socket (G).
7. Place the canopy (A) over the crossbar allowing the mounting screws to go through the canopy (A) and secure with round nuts (B).
8. Refer to the additional installation instructions included with the product of wiring and installation.
9. Restore power to the installation point and retain this sheet for future reference.