

Window Film Fitting Instructions

Thank you for your window film purchase. Please follow these instructions carefully, as they will help you to achieve the optimum result.

Please note, it's often helpful to have two people available to undertake the installation; especially with larger pieces of film.

Before you start installing your window film, please ensure you have the following items to hand:

- A plant spray bottle
- A small quantity of washing up liquid
- Paper towels or a clean cloth for drying
- A sharp craft knife ((or similar) for trimming your film to the frame

Once you have all the items ready, prepare your window by cleaning it thoroughly, taking the time to make sure the surface of the glass is as clean as possible and free from any dirt or dust. Then, fill your spray bottle with water and add a couple of drops of washing up liquid.

You can now start installing your window film.

Step 1: Place your film on a clean, flat surface, ensuring that the backing sheet is facing upwards.

Step 2: While keeping the film flat, slowly remove the backing sheet. Keep the film completely flat while removing the backing sheet, and remove it at a slow, steady pace.

Step 3: With the backing sheet removed, use the spray bottle to cover the window with soapy water. Ensure that the entire surface of the glass is liberally covered with water.

Step 4: Now use the plant spray bottle to cover the exposed surface of the window film. Again, make sure the entire surface of the film is covered with water.

Step 5: Pick up your film and take it to the window. Apply the wet side to the wet surface of the glass, allowing it to flow into place. The soapy water solution will allow you to slide your window film into the exact position that you require.

Step 6: With the film in place on your window, spray the surface of the window film with water and use the supplied application squeegee to push all moisture to the edge of the frame. It's important to spray the film before using the squeegee as this will reduce the friction and prevent damage. Start at the top of the pane and work methodically until all moisture has been pushed to the edge.

Step 7: If necessary, use your sharp knife to carefully trim the excess film at the edges, using the window frame as a guide.

Step 8: With any excess film trimmed and removed, repeat the squeegee process; spraying the film and then using the squeegee to remove all moisture from under the film.

Step 9: Finally, use paper towels or a clean cloth to fully dry the window and frame, taking care not to lift the film at the edges or corners.