

IMPORTANT: Failure to properly install Designer DripEdge® may result in avoidable damage or serious injury. Always wear personal protective equipment when performing installation. Read through all instructions prior to installation. Please contact us at 800-328-5858 with any questions.

Step #1:

Confirm the fit of the Designer DripEdge® with your pull-out waste can. The fit will vary depending on the size of the pull-out door and type of door you have.

Step #2:

Thoroughly clean the top of the door where the Designer DripEdge® will be installed. Remove any external contents and dry the area completely.

Step #3:

Using a rag and rubbing alcohol, wipe the installation area again to remove any remaining dust or residue. Wipe the area until it is dry.

Step #4:

Peel the layer of plastic covering the pre-applied UHB tape on the Designer DripEdge® and attach the Designer DripEdge® to the pull-out door with the tape side on the top of the door.

Be accurate in your placement. If the Designer DripEdge® is placed in an incorrect spot, remove promptly and replace in its proper position.

Step #5:

Hold the Designer DripEdge® tightly against the door and apply reasonable pressure for one minute.

Failure to allow the tape to fully adhere to the door will compromise the integrity of the adhesive and may cause the Designer DripEdge® to loosen.

Step #6:

Clean the Designer DripEdge® with simple cleaning solutions and warm water routinely.

