

ASSEMBLY INSTRUCTIONS

1. Drill 0.5" hole in headboard in the center of where you want the lamp to be when fully assembled and attached
2. Detach cord at coupler (E) and pass the cord with the lamp attached through the hole.
3. Position the Mounting Plate (A) to the headboard and secure using tapping screws provided (B)
4. Attach the Backplate (D) to the Mounting Plate (A) with Mounting Screws (C)
5. Attach cord at coupler (E) and insert plug into nearby outlet.

