

Orifice plates & Installation instructions

For 33 inch Sink (953454)

838.00 mm

791.00 mm

31.14 in

16.14 in

410.00 mm

457.00 mm

Overall Size

Undermount
Dotted Line Model

Undermount Round Conner Cutting(R10)

Installation Instructions Undermount Sinks

| NO | Description | Picture | Qty |
|----|------------------|---------|-----|
| A | Kitchen Sink | | 1 |
| B | Accessories Box | | 1 |
| C | Cut-out Template | | 1 |

Step1: Create A Template

Step2: Fix Nuts Holes According To Instructions Below

Hole Size: $\varnothing 11\text{mm}$ (0.43in) with Depth: 1.5mm (0.59in)

Step3: Install The Nuts

Step4: Install The Kitchen Sink

Position right on