

JRYTIN WOOD FREESTANDING BATHTUB

INSTALLATION INSTRUCTIONS

Model: STT15001



- **Quick Start Guide**

No complicated installation needed!

1. Place the tub on a flat, stable surface.
2. Insert the drain hose securely into your floor drain.
3. Fill with clean, warm water to your preferred depth.

- **Installation**

Tools Required: None

1. Position the tub where you want it.
2. Insert the drain hose into the floor drain.
3. Make sure the tub is stable before filling.

- **Important Notice – Natural Wood Seepage**

Minor water seepage from knots or seams is normal when the tub is new or has not been used for a long time. This is not a defect. Cedar wood naturally loses moisture over time, and soaking the tub helps it re-seal.

To fix seepage:

- Fill the tub completely with water.
- Let it soak for 48–72+ hours.
- The wood will reabsorb moisture, swell, and seal itself.

Tip: If unused for over a month, repeat this soaking process before your next bath.

The JRYTIN Team

