

ASSEMBLY INSTRUCTION

1. FASTEN (B) ONTO (A), PULL EXCESS CORD THROUGH THE BASE YOU ASSEMBLE THE TUBES.
2. FASTEN (C) ONTO (B).
3. FASTEN (D) ONTO (C).
4. PLACE (F) ONTO (E).
5. PUT (G) ONTO (F) AND TIGHTEN IT WITH (H).
6. SCREW BULB INTO SOCKET, BULB (MAX 3WAY 150W) NOT INCLUDED.

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK .THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED . DO NOT ALTER THE PLUG.

