ASSEMBLY INSTRUCTION

ITEM DESCRIPTION: ELEGANCE BARSTOOL

NOTE: DO NOT TIGHTEN BOLTS UNTIL CHAIR IS COMPLETELY ASSEMBLED.

NO DESCRIPTION Q'TY Allen wrench 1PC А <u>ø</u>5/16" Wood screw 6PCS В Lock washer ø5/16" 11PCS С Flat washer ø5/16" 11PCS D Bolt ø5/16"x2-1/4 3PCS Е Bolt ø5/16"x3-1/2 4PCS F Bolt ø5/16"x2-1/2 4PCS G Front leg 👝 2PCS Н Front stretcher 1PC T Left stretcher J 1PC Right stretcher 1PC Κ Seat frame 1PC L Chair back 1PC Μ Glue water 1PC Ν

This page lists all the contents included in the box. Please take

the time to identify the hardware as well as the individual

components to this product. As you unpack and prepare for

assembly, place the contents on a carpeted or padded area to

protect them from damage.

c l e a n i n g & c a r e Treat surface with care. Surface is resistant

to scratches but is not scratch resistant. Clean surfaces with a $\ensuremath{\mathsf{dry}}$

or damp soft cloth. Do not use abrasive cleaners. Hardware may

loosen over time. Periodically check that all connections are tight.



STEP 1: Take 2 pcs front legs (H) and 1 pc front stretcher (I) and assemble as per drawing.

STEP 2: Place seat frame (L) on a smooth, flat surface. Insert front leg assembly from step 1. Using the Allen wrench (A), attach bolts (G), lock washers (C) and flat washers (D) as shown. Do not tighten.





STEP:3



STEP 3: Place chair back (M) on a smooth, flat surface. Position the seat frame assembly from step 2. Using the Allen wrench (A), attach bolts (E), lock washers (C) and flat washers (D) through the central holes as shown. Do not tighten.

Using the Allen wrench (A), attach bolts (F), lock washers (C) and flat washers (D) through the corner holds as shown. Do not tighten.

STEP 4: Position the left and right stretchers J and K and insert with a dab of glue (N). Fix in place using wood screws (B). See diagram.

STEP 5: Place chair on an even floor and balance evenly. Tighten all screws.

