# INSTRUCTION MANUAL ENCLOSED


## **ATTENTION**

IF YOU HAVE ANY PROBLEMS OR QUESTIONS, PLEASE EMAIL OR CALL THE CUSTOMER SERVICE <u>BEFORE</u> YOU RETURN THIS PRODUCT TO THE STORE WHERE YOU PURCHASED FROM.

INSTRUCTION MANUAL ENCLOSED

### **OFFICE CHAIR**

## OFFICE CHAIR ASSEMBLY INSTRUCTION



D. (	PARTS LIST	0 11		
Part	Description  PARTS	Quantity		
A	Seat Back	1		
В	Seat	1		
C	Base	1		
D	Caster	5		
Е	Gas Lift	1		
F	Connection	1		
G	Controller	1		
	HARDWARE			
Н	Bolt M6×20mm	11		
I	Allen Key	1		

Α	В	С	D	Е	F	G	Н	I
			J				M6x20	M 6
Seat Back	Seat	Base	Caster	Gas Lift	Connection	Controller	Bolt	Allen Key
1PC	1PC	1PC	5PCS	1PC	1PC	1PC	11PCS	1PC


### PLEASE READ AND FOLLOW ALL SAFETY TIPS

#### **GETTING STARTED**


1. Before assembly, CAREFULLY use scissors or utility knife to cut and unwrap all parts. Make sure you do not discard the hardware.

#### Warm Tips:


- 1. The plastic covers on some metal parts are just for product protection. Please remove it before assembly.
- 2. Please follow the sequence of AI during assembly.
- 3. Do not tighten the screws until all of them are in right positions.
- \*\*\*Do not fasten the bolts before finishing all steps.
- 1. Place the Base (C) and the Gas Lift (E) in the position showed in Photo 1. Vertically press the Gas Lift (E) into the Base (C). Insert all Casters (D) into the Base (C). Please remember to remove the black cap on the top of the Gas Lift (E) before you take the next step. (Photo 1)




2. Locate the Seat Back (A) and the Seat (B) to the Connection (F) by aligning the pre-drilled holes. Half-fasten the Bolts (H) by hand. Three Bolts (H) and four Bolts (H) are needed in this step. (Photo 2)




3. Install the Controller (G). Four Bolts (H) are needed in this step. (Photo 3



4. Vertically press the upper half in the bottom half.



5. Fasten all Bolts(H) with the Allen Key I (M6).



Till now you have finished the whole assembly.