



COOPER TOILET PAPER HOLDER INSTALLATION

BEFORE INSTALLING

We recommend consulting a professional if you are unfamiliar with installing this type of product. Signature Hardware accepts no liability for any damage to the home, product, or for personal injury during installation.

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Relations at 1.866.855.2284.

Observe all local plumbing and building

TOOLS AND MATERIALS:



Drill



Phillips Screwdriver



Hex Wrench



Drill Bit



Level

INSTALLATION

1

mounting template
mounting bracket

Hold the mounting template at the desired location. Hold each mounting bracket against the wall, and mark the location of the mounting holes on each bracket.

mounting hole

2

hole
anchor
screw

Drill a pilot hole at each marked mounting hole location. **If drilling through tile, you must use a masonry drill bit to avoid cracking the tile.** Insert the anchors into the drilled holes, and secure each mounting bracket to the wall using the provided screws.

3

right base
left base
set screw
hex wrench

Attach each base to the installed mounting brackets. Tighten the set screw located on the bottom of each base to fasten. Ensure that the holes for the roll rod are facing inward, as shown.

4

hole
roll rod
hole

To complete the installation, install the roll rod, as shown. Slide one side of the rod into its hole, press inward, then set the opposite side of the rod in place.