

## INSTALLATION & ASSEMBLY

A    1PC	B    1PC	C    2PCS	D    2PCS
E    4+1PCS	F    2PCS	G    8+2PCS	H    1PC

Dowel Block

① Pay attention to the direction of the feet, the side with 2 pre-drilled holes facing inward

② Pay attention to the direction of the feet, the side with 2 pre-drilled holes facing inward

Please tighten the screws to 70% first, and tighten all screws 100% after all parts are assembled.

③ Tap Dowel Block [D] gently with a rubber mallet to ensure it is secure.

④

Step 1: Attach Corner Brackets [F] to Panel Legs [C] with Screws [G] into pilot holes.

Step 2: Attach Corner Brackets [F] to Board [B] with Screws [G] by a self-tapping method. (No pilot holes)

⑤

If there is any missing, please kindly send us messages to let us know the name of missing part regarding to the first page of instructions.

Please also provide us your full address so we can send replacement to you as soon as possible. We are concerned about each customer's experience, if there is any loss or damage, please contact us at any time. we will provide effective solutions.