



1. First support the left and right sides, insert the cross pipe, (the first layer branch hole is not connected)
2. Plastic cover alignment support small hole, arc aligned below the direction
3. Put steel plate, align the plastic cover, screw the screw
4. The branch hole is connected, as the middle-layer communication, (double or three layers)
5. First put the hook in the horizontal tube, then install the hole position on both sides