

Installation Instructions

Floor Lamp

1. Take all lamp parts out of the package and lay them on a flat surface.
2. Screw tube-**B** clockwise onto base-**A** tightly.
3. Screw tube-**C** clockwise onto tube-**B** tightly.
4. Screw tube-**D** clockwise onto tube-**C** tightly.
5. Screw tube-**E** clockwise onto tube-**D** tightly.
6. Put shade-**F** onto lampholder-**E** and tighten with socket ring-**G**.
7. Install 2 bulbs-**H** (NOT INCLUDED) into the **bulb sockets**.

CAUTION - Refer to the wattage caution label located near the lampholder for recommended maximum wattage-do not exceed recommended wattage.



WARNING - Do not attempt to replace the bulb while the lamp is plugged into a wall receptacle.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (One blade is wider than the other) as a safety feature to reduce the risk of the electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit in the outlet, reverse the plug. If it still does not fit, consult a qualified electrician. Never use an extension cord unless the plug can be fully inserted. Do not alter the plug.

