

# Emma.



FIND A TOOL



SLIDE MATTRESS ONTO  
BEDFRAME



ROLL THE MATTRESS  
UNTIL THE GREY PART  
FACES YOU



CAREFULLY SCORE THE  
PLASTIC WRAPPER  
WITH THE TOOL



ADJUST YOUR MATTRESS  
ON THE BED FRAME & LET  
THE MATTRESS INFLATE



90cm x 190cm



135cm x 190cm



150cm x 190cm



180cm x 200cm