

Invisible canopy installation steps:

1. Put the canopy in the installation position, and use a pencil to make a good hole position marking
2. Expanded pipe size: M10 * 50, use 10mm drill to drill holes.
3. Expanding pipe knocked into the hole in turn
4. Align the holes of the canopy with the holes on the wall, place the circular gasket and tighten the screws. Screw size: M6 * 50
5. For multiple connections, please install one board first and seal it with the sealing strip before checking the hole position of the second board.
6. Put glass adhesive on the wall position and the joints of the adhesive tape.