

# ARM CHAIR

## Assembly Instructions

### Parts List

Chair Leg

Chair Seat

Chair Back

M8 Nut

Flat Washer

Lock Washer

Rubber Cap

### Quantity

2 pcs

1 pc

1 pc

8 pcs

8 pcs

8 PCS

4 PCS

### ASSEMBLY

**We suggest you assemble the chairs on a soft surface to protect the finish.**

**Step 1.** Place the CHAIR SEAT upside down on a soft surface. Attach the LEGS to the seat using M8 NUT, LOCK WASHER, FLAT WASHER. is fitted against the nut and the flat washer between the chair. Finger-tighten at this stage. **The bolts are fitted to the side of the seat.**

**Step 2.** Attach the CHAIR BACK using M8 NUTS, LOCK WASHER, FLAT WASHER. Use the same process as above for attaching the fittings. **The bolts are fitted to the side of the chair legs.**

**Step 3.** Stand the unit upright on a flat level surface. Align the sides with seat and back, so that the unit is level and the legs are parallel. Now tighten the all the nuts firmly, but DO NOT over-tighten. and put the rubber cap on the bolts on the back.

### **Caution:**

The unit is manufactured of cast metal parts and is brittle. DO NOT force any part of the assembly and DO NOT over-tighten the bolts. This could result in serious damage.

