ASSEMBLY TIPS:

Assembly Instruction

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.

| | | ASSEN | ASSEMBLY TIME 20 MINUTES | | | | | | | | | |
|----------------------|--|---|--------------------------|---------|--|----------------------------------|-------|--|--|--|--|--|
| PARTS IDENTIFICATION | | | | | | | | | | | | |
| A | | HEADBOARD PANEL | 1 PC | F | | BED RAIL (WITH "F" LABEL) | 2 PCS | | | | | |
| В | | LEFT HEADBOARD LEG (WITH "L" LABEL) | 1 PC | G [: | | BED RAIL (WITH "G" LABEL) | 2 PCS | | | | | |
| С | | RIGHT HEADBOARD LEG (WITH "R" LABEL) | 1 PC | Н | | BED RAIL SUPPORT LEG | 2 PCS | | | | | |
| D | | FOOTBOARD | 1 PC | I | | BED SLAT | 4 PCS | | | | | |
| Е | | FOOTBOARD LEG | 2 PCS | J | | BED SLAT SUPPORT WITH LEVELER | 4 PCS | | | | | |

| HARDWARE IDENTIFICATION | | | | | | | | | | | | |
|-------------------------|---|---------------|--------|--------|---|-----------------------|--------|--|--|--|--|--|
| 1 | | SHORTEST BOLT | 8 PCS | 7 | 0 | FLAT WASHER | 14 PCS | | | | | |
| 2 | | SHORT BOLT | 8 PCS | 8 | | WOOD SCREW | 8 PCS | | | | | |
| 3 | | MEDIUM BOLT | 10 PCS | 9 Œ | | SMALL ALLEN WRENCH | 1 PC | | | | | |
| 4 | | LONG BOLT | 2 PCS | 10 | | BIG ALLEN WRENCH | 1 PC | | | | | |
| 5 | | WOOD DOWEL | 2 PCS | | | | | | | | | |
| 6 | Ø | LOCK WASHER | 14 PCS | | | | | | | | | |



