

Assembly Guideline

Step 1



Remove the sofa from the vacuum-sealed packaging. Gently fluff it and allow 24 to 72 hours for the bed to fully inflate.

Step 2



Ensure the sponge is fully inserted into the non-slip fabric section with the egg foam side up.

Step 3



Zip up the bottom zipper.

Step 4



Turn the sofa over and unzip the top layer.

Step 5



Insert the bolster into the openings around the sides, then zip up the top layer.

Step 6



Congratulations, your sofa is ready to be used!