

5/8" BAY WINDOW DRAPERY ROD INSTALLATION INSTRUCTIONS

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

SET INCLUDES:

(A) X10 (B) X10 (C) X5 (D) X1 (E) X1 (F) X2
 (G) X1 Extends 36-72"
 (H) X2 Extends 18-36"

YOU WILL NEED:

1/4" dia.

1

Extends 18-36" Extends 36-72" Extends 18-36"

Before installation, measure windows to determine appropriate drapery rod length.

2

Remove screw to separate the bracket (C). Use L-bracket as a guide to mark location for mounting screws (A). Drill pilot holes into wall with 1/4" drill bit (not included).

3

Drywall

Adjustable

Insert wall anchors (B) and attach bracket (C) using mounting screws (A). Wall anchors may not be necessary if drilling into studs. Reassemble the bracket (C), adjusting to desired depth. Tighten screw to secure.

4

6 inches

Repeat steps 2-3 for additional brackets. Use level if necessary. Note: Center bracket may not be needed for all applications.

5 CENTER ROD

Extend telescoping rod (G) slightly. Place drapery panels (not included) on the rod. Insert corner connectors (F) into each end of the rod.
Note: Smaller post fits to smaller diam. rod, larger post fits to larger diam. rod.

6 CENTER ROD

Extend rod to desired length. Hang rod on brackets (C).