



Landscape lighting will be installed by professional.

- Turn off power.
- Open water shield and install PAR16/PAR20/PAR30/PAR38 incandescent.
- Rotate water shield into desired direction.
- To connect wires using wire nuts each supply wire to corresponding socket wires.
- Attach Landscape floodlight to stake post or canopy.
- Turn on power.

