

THANK YOU FOR PURCHASING THE FLOOR LAMP.
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

ASSEMBLY INSTRUCTIONS:

1. UNPACK ALL PARTS FROM CARTON CAREFULLY AND LAY ON FLOOR;
2. SCREW THE CENTER TUBE("D") CLOCKWISE TO THE CENTER OF BASE,
THEN REPEAT THE PROCESS WITH THE TUBE("E") AND TUBE("F").
3. SCREW THE TUBE("A I ") CLOCKWISE TO THE BASE.
4. SCREW THE TUBE("A II ") CLOCKWISE TO THE TUBE("A I ").
5. SCREW THE TUBE("AIII") CLOCKWISE TO THE TUBE("A II ").
THE TUBES HAVE BEEN MARKED "A" OR "B"
PLEASE CONNECT THE TUBES "A" WITH "A" "B" WITH "B"
6. REPEAT THE PROCESS WITH THE TUBE("B") AND TUBE("C").
THEY ARE 3 SETS TUBES AND MARKED A/B/C TO DIFFERENTIATE,
PLEASE DO NOT MIX TO ASSEMBLE THE TUBE.
7. SCREW THE TUBE("G") CLOCKWISE TO THE CENTER TUBE("F").
8. SCREW THE TUBE PART("H") CLOCKWISE TO THE TUBE("A III").
9. PLACE THE PART("I") ONTO THE TOP OF TUBE("A/B/C") PROPERLY , AND
SCREW THE BUTTERFLY NUT ("J") CLOCKWISE TO FIX THE PART("I").
10. PULL EXCESS POWERCORD OUT OF BASE THEN PLACE THE PART("K") ONTO THE
TOP OF PART("I") , AND SCREW THE PART("L") CLOCKWISE TO FIX THE PART("K").
11. PLACE THE GLASS SHADE("N") ONTO THE TOP OF SOCKET("M") , AND
SCREW THE SOCKET RING("O") CLOCKWISE TO FIX THE GLASS SHADE("N").

