Specifications

DESCRIPTION


·Solid brass construction
·Premium finish resist corrosion and tarnishing
·Feature a waterfall spout
·Hand shower with back flow protection
·60"(1500mm)rubber hose included
·Feature a pressure balance valve
·Suitable for wall mounted rough-in installation


CARTRIDGE


·Ceramic disk cartridge
·Pressure-balanced valve

Wall Mounted Bathtub Faucet

NOTE:THIS FAUCET IS DESIGNED FOR WALL MOUNTED ROUGH-IN INSTALLATION











Wall Mounted Bathtub Faucet Installation

INSTALLATION MANUAL Tools You will need


Adjustable Wrench


Allen key


Philips Screwdriver


Teflon Tape

Before the Installation

1.Check the package and confirm all parts are included. If any part is missing or damaged, please contact us.

2.Do not disassemble the main body,as it has been installed & commissioned correctly & precisely before leaving the factory.

3.Shut off the main water supply prior to beginning installation.

4.Do flush the water supply lines to remove any dirt and debris before installation **(IMPORTANT) .**

5.Make sure to connect the hot/cold inlet pipe correctly.If standing in front,connect hot water pipe to the left and cold water pipe to the right.


6.After the installation,check for leaks and make sure every joint is safely sealed.

Cleaning and Maintenance


1.Rinse with clean water and dry with a soft cloth.

2.Do not use any detergent,acid,polisher,abrasives,or harsh cleaners.


3.Do not use cloth with a coarse surface.




1.Acoording to the site condition and the installation size requirement and to make a hole,the hold size is 180mm(length)*130mm (width)*65-75mm(deep).




2(1).According to the site condition and the installation size requirement to set up the pipe line.(2).Connect the plastic box to the pipe,put the plastic box on the hole,then adjusted the levels(the bubble on the middle of the leveller).(3).Make the positioning holes.




3.Remove the protective cover when the finished wall is completed and install the escutcheon (B) to the valve (A) and press it against the finished wall.Then, install the handle (C) and diverter knob (D),tighten set screws (E) with Allen key (F),and put on the indication buttons (G).



4.Turn the water on for 1 minute to flush any debris. Apply Teflon tape (H) to the threaded tail pipe and install the shower hose (I) into the outlet on the wall,Then connect the top shower (P) to the spout.



5.Apply Teflon tape (H) to the threaded end,the fix the cover plate (J) onto the wall supply holder (K) and screw the wall supply holder (K) into the hand shower outlet.



6.Add rubber washers (L) at both ends of the shower hose (M).Connect shower hose (M) to the wall supply holder (K) and hand shower (N).Then, place the hand shower (N) to the wall supply holder (K).