


PARTS:


(2) Side Piece



(2) Top/Bottom Piece




(3) Shelf Piece (back grooves both sides)



(20) Hex Screws



(4) Back Pieces




(1) Allen Wrench




Notice - KEEP BACK GROOVES ALIGNED


Step 1: Insert edge of **bottom** piece into mortise of **side** piece as shown, making sure to align back grooves. Insert hex screws into each of (2) pre-drilled holes in **side** piece and tighten down halfway.




Step 2: Insert edge of **top** piece into opposite mortise of **side** piece, making sure to align back grooves. Insert hex screws into each of (2) pre-drilled holes in **side** piece and tighten down halfway.




Step 3: Insert edge of **shelf** piece into mortise of **side** piece, making sure to align back grooves. Insert hex screws into each of (2) pre-drilled holes in **side** piece and tighten down halfway.



Step 4: Insert edge of **shelf** piece into mortise of **side** piece, making sure to align back grooves. Insert hex screws into each of (2) pre-drilled holes in **side** piece and tighten down halfway.




Step 5: Insert edge of **shelf** piece into mortise of **side** piece, making sure to align back grooves. Insert hex screws into each of (2) pre-drilled holes in **side** piece and tighten down halfway.





ASSEMBLY INSTRUCTIONS

Notice - KEEP BACK GROOVES ALIGNED


Step 6: Insert sides of a remaining **back** piece into back grooves of two **shelf** pieces. Slide down until edge rests firmly in back groove of **side** piece.



Step 7: Insert sides of a remaining **back** piece into back grooves of **shelf** pieces as shown. Slide down until edge rests firmly in back groove of **side** piece.




Step 8: Insert sides of a remaining **back** piece into back grooves of **shelf** and **bottom** piece as shown. Slide down until edge rests firmly in back groove of **side** piece.



Step 9: Insert sides of last remaining **back** piece into back grooves of **shelf** and **top** piece. Slide down until edge rests firmly in back groove of **side** piece.

Step 10: Insert edges of assembled pieces into mortises and back grooves of remaining **side** piece. Insert hex screws into each of (10) pre-drilled holes in **side** piece and tighten down halfway.



Step 11: Tighten all screws until snug. DO NOT OVER TIGHTEN. DO NOT DRILL. Rotate unit so that it rests on **bottom** piece and edges of **side** pieces. **Assembly is now complete.**

