

## INSTALLATION INSTRUCTION



1. Secure the housing into the hole.



2. Attach the trim using the spring clips.



3. Screw the bulb into the socket.



4. Installation is now complete.