

SURFACE STYLE™

PEEL AND STICK WALLPAPER

Removable, Repositionable & Easy to Install

Pattern No.

Design

Run/Lot

20.5 in x 6 yd, 30.75 ft² (52.1 cm x 5.5 m, 2.85 m²)

Design Match:

Repeat:



Inspection

Be sure you've got plenty of rolls to complete your project, accounting for design repeats! Also, double-check that the pattern and lot numbers match on all rolls before you start. While we carefully inspect and test our wallcoverings, it's always a good idea to take a quick look for any defects before hanging. Just a heads-up – we're not responsible for labor charges related to installation or removal, or for any issues from improper hanging. Once you hang more than one strip, you're all set and accepting the product. Happy decorating!

Hanging Instructions

1. Measure the height of your wall and precut the strips to match, remembering to add an extra 1-2 inches at the top and bottom for trimming. Make sure to line up the pattern with each panel before cutting, and don't forget to number each panel as you go. Use a sharp razor knife to cut and trim the product and be sure to change the blade regularly to keep your cuts smooth.
2. Begin on the left side of your wall or surface. Measure 20.5" (52cm) from the corner and mark it lightly with a pencil. Using a level, draw a straight vertical line — this will be your guide for the first strip, so make sure it's nice and straight. If you're creating a feature wall, we suggest starting in the center to achieve a balanced look.
3. Peel back about 12" (30.48cm) of the backing from the paper. Start by applying the top of the paper to the wall, letting the extra 1-2 inches overlap the ceiling (this will be trimmed off later). Align the right side of the strip with your vertical line and gently press the edge to the wall along the line. If needed, you can reposition to make sure the seam is vertical. Working from top to bottom, carefully peel the backing away as you press the paper onto the wall. **Don't force the paper and avoid pulling or stretching it to ensure the pattern stays aligned.** For the best results, we recommend having one person guide the paper at the top and along the seam, while the second person holds the opposite edge away from the wall until the seams align. We recommend overlapping the seams by 1/16" between adjacent panels to prevent any shrinking from temperature changes.

Preparation

Before you start, make sure your wall is clean, dry, smooth, and free of any mildew. We do not recommend applying to textured walls, existing wallpaper, brick, cinderblock, non-stick paint, unpainted drywall, outdoor surfaces, or plaster. If your wall's freshly painted, just give it about 4 weeks to fully cure before applying.

Tools: Tape measure, Utility knife, Level, Pencil, Smoother, Straight Edge

4. Using the plastic smoother, gently work your way down the strip in a back-and-forth motion, smoothing the material onto the wall and pushing out any air bubbles.

5. Trim any excess material at the ceiling and baseboard using a ruler and sharp razor for a clean finish.

6. Repeat the process, aligning the next strip with the right edge of the previous one.

Removal

To remove, gently pull the edge from the top corner and slide it downward. The material can be repositioned and easily removed.

Cleaning

You can wipe the material clean with a damp cloth, but we advise against using too much liquid, as it could damage the product.

SURFACE STYLE™
PEEL AND STICK WALLPAPER

Copyright © 2025 All Rights Reserved

Made in USA