

 Please tighten the screws together **at the last step** for your better assembly experience.



**STEP 1:**

20%

Prioritize attaching screws to the lower holes of the rod, **but do not tighten the screws thoroughly**



**STEP 2:**

50%

Flip the seat over to the front and fix it with screws through the holes of the rod



**STEP 3:**

80%

Install the adjustment rod of the backrest into the corresponding hole



**STEP 4:**

100%

Fully tighten all screws