ASSEMBLY INSTRUCTION

317-622L/M Ladderback Chair 317-636L/M 317-638L/M

Splat back Chair Rake back Chair

HARDWARE LIST						
Α		Bolt	Ø5/16"*3-1/2"	4 PCS		
В		Bolt	Ø5/16"*1-3/4"	2 PCS		
С		Nut	Ø5/16"	4 PCS		
D	Ø	Lock Washer	Ø5/16"	10 PCS		
E	0	Flat Washer	Ø5/16"*19D	10 PCS		
F		Allen Key	100*50*4mm	1 PC		
G		Spanner Wrench	12MM	1 PC		
Η		Screw	Ø8*1-3/4"	4 PCS		

PART LIST				
1	Chair Back	1 PC		
2	Seat Frame + Wood Seat	1 PC		
3	Left Front Leg	1 PC		
4	Right Front Leg	1 PC		
5	Stretcher Frame	1 PC		
6	Seat Cushion	1 PC		

IMPORTANT NOTES

- . Place all wooden parts on clean and smooth surface such as rug or carpet to prevent the parts from being scratched.
- . Check to be sure that you have all parts and hardware.
- . Remove all wrapping materials, including staples and packing straps before you start to assemble.
- . Do not tighten all screws and bolts until completely assembled.
- . Keep all hardware out of the reach of children

Option 1



STEP 1. Place chair back (1) on a clean & padded surface then attach seat frame + wood seat (2) to the chair back using bolt (B), lock washer(D), flat washer (E), and tighten with allen key (F). Important: Do not over-tighten. STEP 2. Attach back assembly to the seat frame + wood seat (2) using bolt (A), lock washer (D), flat washer (E), and tighten with allen key (F). Important: Do not over-tighten.



STEP 3 .Attach the left front leg (3) and right front leg (4) to the seat frame + wood seat (2) using nut (C), lock washer (D), flat washer (E), and tighten with spanner wrench (G). Important: Do not over-tighten.

MADE IN VIETNAM

ASSEMBLY INSTRUCTION

317-622L/M	Ladderback Chair
317-636L/M	Splat back Chair
317-638L/M	Rake back Chair

Option 1



MADE IN VIETNAM