## ORIGINAL CEDAR RAISED GARDEN BED | ASSEMBLY INSTRUCTIONS

## PACKAGE CONTENTS + (6) Screws Short Posts Stacked on top of Tall Posts X6 X6 X6 Short Posts Stacked on top of Tall Posts Short Posts Short Posts Short Posts Short Posts Short Posts Tall Posts Tall Posts

## CONNECT THREE TALL POSTS TOGETHER WITH TWO BOARDS

Holding a Board in one hand with the notched ends facing up, line up the groove on a Tall Post and slide it down over one end of the Board. Slide another Tall Post down over the other end. With the same Tall Post, slide the second Board through the groove finishing with another Tall Post at the end to complete one 8ft. wall. Repeat step one to complete a second wall.

2. CCONNECT THE TWO WALLS TOGETHER WITH THREE BOARDS

Take a Board and slide down over the top of a Tall Post. Connect the same Board to an adjacent Tall Post on the second wall. Do the same with two more Boards completing a  $4 \, \text{ft.} \times 8 \, \text{ft.}$  rectangle or two connected  $4 \, \text{ft.} \times 4 \, \text{ft.}$  squares.



ADD A SECOND AND THIRD BOARD TO ALL WALLS AND ADD THE SHORT POSTS.

Add Boards, one at a time, directly on top of each existing Board in the Frame. Push the Boards down evenly between the tops of the Tall Posts. If needed, tap snugly into place with a rubber mallet. The Boards should extend beyond the first set of Tall Posts by a few inches. Take the Short Posts and slide them down over the tops of the Boards.

4. FINISH WALLS & ATTACH DECORATIVE CAPS

Now slide the remaining Boards down into the Short Posts to finish each of the walls. Attach each Decorative Cap to a Short Post with a screwdriver and one Screw. We recommend drilling a pilot hole first for each Screw.



