

INSTALLATION INSTRUCTIONS

**Install Damper, spacer, and reducer on top of the 6" duct exit.
Tape all parts together and connect 5" round ductwork**

