

HOW TO INSTALL GLOW IN THE DARK HOUSE NUMBERS

Package contents: number frame, glow insert and install kit.

01

Mark the area for the frame and drill the holes on the wall.

02

Insert the plastic anchor & screw the frame using a screwdriver.

03

Use the provided 3M tape, cut it to size and add it to the glow insert

04

Insert the glow in the frame and hold it for 30 seconds. Make sure the 3M tape holds.

Silicone can be used as an alternative
(not included in the kit)

www.itglows.ca