| ASSEMBLY | INSTRUC | CTIONS |
|----------|---------|--------|
| | | |
| | | |
| | | |
| | | |

ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

▲WARNING!

1.Don't attempt to repair or modify parts that ate broken or defective. Please contact the store immediately. 2.This product is for home use only and not intend for commercial establishment.

ASSEMBLY TIME PER UNIT 5 MINUTES

PARTS IDENTIFICATION

| А | Back | | 1PC |
|---|-----------|---|------|
| В | Seat | 000000000000000000000000000000000000000 | 1PC |
| С | Front Leg | | 2PCS |

| | HARDWARE PACKAGE | | | | |
|---|------------------|--------------|-------|------|--|
| 1 | SHORT BOLT | (Marin 1977) | M8*55 | 1pcs | |
| 2 | LARGE BOLT | | M8*60 | 4pcs | |
| 3 | LARGEST BOLT | <u>@</u> | M8*80 | 4pcs | |
| 4 | ALLEN KEY | | M8 | 1pcs | |
| 5 | LOCK WASHER | © | | 9pcs | |
| 6 | FLAT WASHER | 0 | | 9pcs | |

