9729 Full / Queen Headboard



Queen Bed

Assembly Instructions



Page 1 of 5













Bolt & screw the Bed Slats (H) to the Side Rail (C).

