

Assembly Instruction-1015

A*1	
B*1	
C*1	
D*10	
E*20	 M6X 30mm
F*6	 M6X 25mm
G*1	 spanner

Step 1

B

D

E

G

E

80%

Step 2

C

D

E

G

E

80%

100%

Step 3

A

D

F

G

F

80%

100%

Finish

Adjustable