

INSTALLATION PROCEDURE



1. Install the universal pulley first



2. Insert the tube into the hole



3. Alignment hole installation



4. Stacking installation in sequence



5. Put a plastic cap on the top



6. installation is complete