



**INSTALLATION HINTS:** Locate proper position on top of window rail allowing 2 to 3 inches of ventilation. Mark hole locations and drill 3/32 in. pilot holes. Screw vent lock in place using screws provided. To lock window in ventilation position, flip tab to it's horizontal position. To open the window fully, flip lock into vertical position, clearing the window to pass.

**CONSEJOS PARA LA INSTALACION:** Localice la posición apropiada encima de barra de la ventana que permite 51 mm a 76 mm de ventilación. Mark las situaciones del agujero y taladra 2 mm los agujeros modelos. La cerradura de abertura de tornillo en lugar que usa los tornillos proporcionado. Para cerrar con llave la ventana en la posición de ventilación, la etiqueta del capirotazo a él es la posición horizontal. Abrir la ventana totalmente, la cerradura del capirotazo en la posición vertical, que aclara la ventana para pasar.

**CONSEILS D'INSTALLATION:** Localisez la place adéquate sur rail de la fenêtre qui autorise 51mm à 76 mm de ventilation. Marquez des emplacements du trou et forez 2 mm trous pilotes. Serrure de la prise d'air du vis dans place qui utilise des vis fournie. Enfermer la fenêtre dans place de la ventilation, retournez l'étiquette à lui est place horizontale. Ouvrir complètement la fenêtre, retourne la serrure dans place verticale, en clarifiant la fenêtre pour passer.