



1. Match each side Rail with its correct base bracket Location (either by Number or Letter)
2. Unscrew bolts
3. Align & Insert Rail in to the groove provided in the headboard.
4. Attach Rail to the headboard using the bolts as shown below



5. Follow the same for the other Bed Rail. Make sure all the bolts are securely fastened.
6. Insert the center support into the groove provided in the headboard & foot board.
7. Insert all the slats into the slots provided.