



# ASSEMBLY INSTRUCTION

DESCRIPTION : 2 DOORS SHOE CABINET

<b>HARDWARE</b>	<b>A</b> 16MM CB SCREW M3.5X16MM 1X20	<b>B</b> 38MM CB SCREW M4X38MM 1X4	<b>C</b> NAIL 5/8 1X16	<b>D</b> D1 D2 3.5 KG MAGNET (1 HOLE) 2 SETS	<b>D3</b> CB SCREW M3X12MM 1X8	<b>E</b> PVC SHELF SUPPORT 1X8	<b>F</b> DOOR SUPPORT SPRING 1X2	<b>G</b> G1 G2 MAS R4 MAS L4 1X1 1X1	<b>H</b> ROUND PLASTIC LEG (PVC) 1X4	<b>I</b> I1 I2 MINIFIX 5654-5546 4 SETS	<b>J</b> L-KEY 1X1	<b>K</b> QUICKFIT CAP 1X4	<b>L</b> HANDLE 5022 (METAL) M4X22MM 1X2	<b>M</b> 22MM HANDLE SCREW M4X22MM 1X2

**PART LIST**

**STEP 1**

**STEP 2**

**STEP 3**

**STEP 4**

**STEP 5**

**STEP 6**

**STEP 7**

**STEP 8**

**STEP 9**

**COMPLETED**

**STEP 10**

**STEP 11**

**STEP 12**