


Assembly Instructions



“Please check all parts and hardware against the list before assembly. If any parts are missing or damaged, please contact us immediately.”


Before Assembly

1. Assembly requires two or more people to complete.
2. Using power tools will make the installation finish faster.

Tips Before Your Start:


- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until the assembly is completely assembled.
- Keep all hardware parts out of reach of children.

QUICKFIT




Tighten quickfit until shoulder is flush with panel. Do not overtighten or undertighten.

CAM LOCK




When fitting a cam lock, ensure the starting position is correct before inserting the connecting QUI CKFIT

"Ensure the arrow on the Cam Lock (B) is pointing towards the hole for the Cam Lock Dowel (A) before inserting."



Turn cam lock clockwise to tighten.

Product structure













“Assemble on a soft surface, such as a carpet or the original packaging box, to avoid scratches to the panels.”


Part List




“Please check all parts and hardware against the list before assembly. If any parts are missing or damaged, please contact us immediately.”

No. A Quantity: 30 Pcs Cam Lock Dowel 8*28mm 	No. B Quantity: 30 Pcs Cam φ15 	No. C Quantity: 30 Pcs Sticker Ø20 	No. D Quantity: 18 Pcs Dowel 8*30mm 
No. E Quantity: 4 Pcs Large curved door hinge 	No. F Quantity: 4 Pcs Mid bend door hinge 	No. G Quantity: 48 Pcs Screw M3.5*12mm 	No. H Quantity: 2 Pcs Screw M6*40mm 
No. I Quantity: 4 Pcs Foot Pad Ø12 	No. J Quantity: 8 Pcs Shelf Support M5*15mm 	No. K Quantity: 1 Pc Allen Key 4# 	No. L Quantity: 1 Pc Adjust The Foot 
No. M Quantity: 16 Sets Plastic Wedge 	No. N Quantity: 2 Sets Anti-falling Parts 		

STEP 1




No. A
Quantity: 6 Pcs
8*28 mm



STEP 2

Please pay attention to the direction when installing


No. D
Quantity: 2 Pcs
8*30mm




No. H
Quantity: 2 Pcs
M6*40mm



No. K
Quantity: 1 Pc
4#




Please pay attention to the direction when installing



STEP 3


Please lift the slats on both sides by hand to prevent the ends from hanging and damaging the wood.




No. B
Quantity: 6 Pcs
Ø15




No. C
Quantity: 6 Pcs
Ø20




STEP 4




STEP 5



No. A
Quantity: 16 Pcs
8*28 mm



STEP 6




No. B
Quantity: 10 Pcs
Ø15




No. C
Quantity: 10 Pcs
Ø20




No. D
Quantity: 4 Pcs
8*30mm



STEP 7



STEP 8




No. I
Quantity: 4 Pcs
Ø12




No. L
Quantity: 1 Pc




STEP 9



No. A
Quantity: 8 Pcs
8*28 mm



STEP 10




No. B
Quantity: 4 Pcs
Ø15




No. C
Quantity: 4 Pcs
Ø20



No. D
Quantity: 4 Pcs
8*30mm



STEP 11



STEP 12




No. B
Quantity: 10 Pcs
Ø15




No. C
Quantity: 10 Pcs
Ø20




No. D
Quantity: 8 Pcs
8*30mm




STEP 13




No. J
Quantity: 8 Pcs
M5*15mm




STEP 14



The way to adjust the door by hinge.





If the gap is too big between side panel and door or the door is over the edge of side panel, loose the back screw as shown, then move in the door with hinge and tighten the back screw as shown when the gap is just well.





If the gap is too small between side panel and door or the door sank in side panel, loose the back screw as shown, then move out the door with hinge and tighten the back screw as shown when the gap is just well.



! IMPORTANT: When making height or depth adjustments, please ensure you adjust **BOTH** the top and bottom hinges of the door simultaneously. Adjusting only one hinge will be ineffective and may cause stress on the hardware.




If the gap is too small between two doors, loose the front screw as shown.



If the gap is too small between two doors, loose the front screw as shown.




Attention:
After adjusted Hinges,
then lock screws.





If the doors are not in same level, losse the back screws on wing, then adjust the door up and down, tighten the screws when both doors are in same level.Screw front two screws on wing when all are in place.

STEP 15

No. E
Quantity: 4 Pcs





No. G
Quantity: 8 Pcs
M3.5*12mm



STEP 16

First, use screws to secure the two rear guide holes of the door hinge into the two guide holes of the side panel.




No. G
Quantity: 16 Pcs
M3.5*12mm





If you encounter difficulties during adjustment, please refer to the guidance on pages 11 and 12 to adjust the gaps of the cabinet doors. After making the gaps even, please tighten the two screws on the front side.

STEP 17

No. F
Quantity: 4 Pcs






No. G
Quantity: 8 Pcs
M3.5*12mm



STEP 18

First, use screws to secure the two rear guide holes of the door hinge into the two guide holes of the side panel.



No. G
Quantity: 16 Pcs
M3.5*12mm





If you encounter difficulties during adjustment, please refer to the guidance on pages 11 and 12 to adjust the gaps of the cabinet doors. After making the gaps even, please tighten the two screws on the front side.

STEP 19



“DO NOT skip Step 19. The Plastic Wedges (M) are crucial for the stability of the cabinet.”




Description: Insert the thinner end of the reinforcement into the gap in this back panel, then tighten the screws. This will make the cabinet more stable.

No. M
Quantity: 16 Sets









STEP 20




STEP 21



WARNING: ALWAYS LIFT the cabinet when moving it. **NEVER DRAG** it across the floor. Dragging will cause the legs to fail and may lead to serious injury or property damage.



No. N
Quantity: 2 Sets



Note:
Please lift up the furniture by two people when moving is needed. Dragging may cause the legs failure.