

# Recessed Paper Towel Holder

Installation Guide for use with Part Numbers:

Recessed\_PT\_Holder 20210717

1. Find studs in wall to locate an appropriate wall space between studs.
2. Use a level and the back of the box for aligning then mark an outline of the cutout.
3. Cut opening neatly to the mark with appropriate tool for the wall material.
4. Dry fit box into wall opening and check for fit.

The Recessed Paper Towel Holder may then be affixed using one of the two suggested methods below.

## Method A:

- A1. Using painter's tape, mask the wall adjacent to the trim to prevent smearing of adhesive.
- A2. Choose an appropriate construction adhesive and apply to the opening's sides and wall face.
- A3. Hold in place as directed by adhesive instructions. Leaning a heavy object, such as a chair, against the box should suffice.

## Method B (More advanced. Consult builder or renovation specialist if unsure.):

- B1. Cut two 2x4 blockings to span studs.
- B2. Slip into opening, check level, and toenail screw into place (above and below) aligned to previous marking's opening in wall.
- B3. Insert box into opening and check fit.
- B4. Apply adhesive to blocking, insert box, and hold in place  
-or- use screws as below:  
Drill and countersink for single screw into upper and also lower supports.  
(#8 or #9 construction screws recommended. Drill approx. half diameter of screw threads.)
- B5. Woodfill or painters caulk over screw heads.