



by Stevens Industries, Inc.
704 West Main St.
Teutopolis, IL 62467
P: 800.350.3270
P: 217-857-7100
F: 217-857-7101
www.totmate.com

TM2336R

TM4336R

Diaper Wall Storage

TM2336R

HARDWARE BAG# 0563-3310



TM4336R

HARDWARE BAG# 0563-3341



CAUTION – CHOKING HAZARD

Adult assembly required due to presence of small parts and sharp edges.

Illustrations and part numbers are for TM2336R.

Basic assembly instructions are the same for models shown. 2-Person assembly recommended.

ATTENTION

Please unpack and assemble in an area away from children's activities. Remove all tools and excess materials from work area after assembly of unit is complete. Dispose of pallet and packaging materials in an environmentally friendly manner. If any parts are missing or damaged, please call Stevens for immediate parts replacement (1-800-350-3270). When ordering parts, give the Model Number and Color of the unit.

NOTE: Refer to exploded drawing for orientation of holes to parts.

IMPORTANT!

Be sure to keep all parts supported during assembly to avoid damage. Do not over-tighten bolts or it will damage the pre-drilled holes. Snug fit is adequate.

PARTS for TM2336R

ITEM	QTY	DESCRIPTION
1	2	End
2	1	Bottom
3	1	Shelf, double grooved
4	5	Subdivider
5	2	Stringer
6	1	Top
7	3	Divider
8	2, 1	Back (2 for TM2336R, or 1 for TM4336R)
9	10	Clip, Shelf 1/4" x 224mm
10	21	Screw Conn HxDc Ni, 7mm x 50mm
11	1	Screw Conn HxFl ZN 7mm x 50mm

TM4336R ONLY:

12	2	Screw Tapp PhWh Zinc #8 x 1.25
----	---	--------------------------------

HARDWARE / TOOLS INCLUDED


(Phillips screwdriver required but not included.)




Confirmat Bolt
(Screw Conn HxDc Ni 7mmx50mm)



Hex Wrench



Flat Head Confirmat Bolt
(Screw Conn HxFl ZN 7mmx50mm)



Back Screw
(TM4336R only)
(Screw Tapp PhWh Zinc #8x1.25)



Shelf Clip
(Clip Shelf/Divider 1/4" x 224mm)

- STEP 1:** Locate **Top (6)**, **Bottom (2)** and **Shelf (3)**. Note that **Shelf** has one set of three holes on one side and two sets of three holes on the other side. **Bottom** has two sets of three holes on one side. These are for **Dividers (7)**
- STEP 2:** Lay **Bottom (2)** on floor, with side having routed groove and the most holes facing up. Insert **Divider (7)** dowels into holes on **Bottom (2)**, making sure raw edges of **Dividers** are facing same direction as groove on **Bottom**.
- STEP 3:** With side having the most holes facing down, align holes on **Shelf (3)** with dowels on standing **Dividers (7)**. Make sure all raw edges are facing same direction. Press firmly into place.
- STEP 4:** Secure **Shelf (3)** and **Bottom (2)** to **Divider (7)** with four **Confirmat Bolts (10)** using **Hex Wrench**.
- STEP 5:** Insert remaining **Dividers (7)** into holes on **Shelf (3)**.
- STEP 6:** Align holes on **Top (6)** with dowels on **Dividers (7)**. Make sure routed groove on **Top** and all raw edges are facing same direction. Press firmly into place.
- STEP 7:** Secure **Shelf (3)** to **Divider (7)** with **Flat Head Confirmat Bolt (11)**. Secure **Top (6)** to **Divider (7)** with **Confirmat Bolt (10)**.

This completes the SHELF DIVIDER ASSEMBLY.

- STEP 8:** Lay one **End (1)** on floor with side having the most holes facing up.

- STEP 9:** Insert **Shelf/Divider Assembly** into holes on **End (1)**. Make sure the double groove is toward the back (flat) edge of **End (1)**.
- STEP 10:** Slide **Backs (8)** into grooves on **Top and Shelf**, and on **Bottom and Shelf**. Seat firmly against the **End**.

Model TM4336R does not have grooves on Ends (1). Attach Back by inserting two Back Screws (12) through holes into shelf.

- STEP 11:** Insert dowels on **Stringers (5)** into remaining holes on **End**. Make sure holes on **Stringers (5)** align with thru-holes on **End**.
- STEP 12:** Position other **End** on top of assembly, so dowels on **Shelf/Divider Assy** and **Stringers (5)** align with holes on **End**. Press firmly into place.
- STEP 13:** Secure **End (1)** to **Shelf/Divider Assy** and **Stringers (5)** with eight **Confirmat Bolts (10)**.
- STEP 14:** Carefully turn unit over so other **End** is facing up. Repeat Step 13 to secure other **End** to **Shelf/Divider Assy** and **Stringers**.
- STEP 15:** Carefully lay unit onto back and insert **Shelf Clips (9)** into remaining holes on **Bottom** and **Shelf**. Slide **Subdividers (4)** into **Shelf Clips**, ensuring rounded edges are facing front of unit.
- STEP 16:** Carefully stand unit upright. Ensure all joints and bolts are tight.

This completes the assembly.

