

STOVE COVER ASSEMBLY INSTRUCTION



WE STRONGLY RECOMMEND THAT THE PRODUCT IS ASSEMBLED ON A FLAT AND SMOOTH SURFACE AND KEEP ON THE SAME HORIZONTAL LINE, OTHERWISE, THERE WILL BE A PHENOMENON OF SCREW DISLOCATION AND CANNOT BE INSTALLED.

x1 PCS 	x2 PCS 	x4 PCS 	x1 PCS 
---	---	--	---



NOTE: BOLTS SHOULD BE SCREWED ON THE COUNTERBORE