CEDAR ELEVATED GARDEN BED ASSEMBLY INSTRUCTIONS





2.

CONNECT LEG POSTS TOGETHER WITH FLOOR SUPPORT BLOCKS

Stand two Leg Posts upright. Holding both ends of a Floor Support Block with the notched ends facing up, slide both ends into the grooves of the Leg Posts with even pressure, all the way to the bottom. Connect the remaining Leg Posts and Floor Support Blocks the same way, with long and short Floor Support Blocks opposite each other to form the rectangular frame.



DROP IN FIRST SIDE WALL BOARD

Stack one Side Wall Board over each Floor Support Block. Tap both ends of the Side Wall Board evenly so it slides securely down between the Leg Posts. If needed, tap snugly into place with a rubber mallet.



DROP IN FLOOR BOARDS

Lay the Floor Boards side by side on the ledge created by the Floor Support Blocks, leaving a gap between each Board for drainage. If using the Fabric Liner, fold or cut it to size and lay on top of the Floor Boards. It will stay in place when soil is added.

FINISH WALLS & ATTACH DECORATIVE CAPS 4.

Now stack the remaining Side Wall Boards as shown in Step 2 to finish the walls. Attach each Decorative Cap to a Leg Post with a screwdriver and one Screw. We recommend drilling a pilot hole first for each Screw.





