



1. Remove the lock nut & teeth lock washer from light fixture ②.

2. Let the wire go through canopy ④, teeth lock washer, ground wire, lock nut, rotate the lock nut to fix the canopy to the fixture.

3. Install the bracket to the junction box with screw ⑥.  
 4. Connect the wire to your home line.  
 5. Install the fixture to the bracket with cap nuts ⑤.  
 6. Install the lampshade ⑧ to the bulbholder with socket ring ③.  
 7. Install the bulbs ⑨.

**B0165-1**

**Please read carefully before installation!!!**  
**Note : Please make sure that the electricity is powered off during installation !**  
**Only a professional electrician should install this kind of product !**