



Assembly Instructions for 8733 - Rectangular Directoire Table

A. Attach the legs to the black "X" brace (using phillips screws), matching the colored dots, counter sinking the screws in the predrilled holes. (The colored dots on the black "X" are facing up in figure A)

B. Lay the marble top face down on a protective surface.

C. Attach the assembled "X" brace and legs to the marble top (using the remaining phillips screws) matching the colored dots. A minimum of 1 screw per arm is required to secure the top to the "X" brace.

D. Attach the brass side braces to the legs using the button screws.

E. Turn upright by lifting the marble (Do not lift by the legs).

Figure A



Figure B

