

ASSEMBLY INSTRUCTIONS

Description: Pendant

These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning installation of this chandelier. **We strongly suggest that all hard wired fixtures be installed by a professional electrician.**



Parts Included:

1. Main Body
2. Mounting spider
3. Canopy
4. Glass Pieces (01Pcs)

Hardware Enclosed:

1. (2) Mounting Screws
2. (2) Plastic Wire Connectors
3. (1) Green ground screw

To Install You Will Need:

1. 2 people recommended
2. Phillips Screwdriver (Not Provided)
3. Electrical tape (Not Provided)
4. Wire cutters (Not Provided)

To Assemble:

1. Carefully remove the protective covering on the iron frame.
2. We recommend two people install this pendant. At this step, one person is needed to hold the pendant while the other screws the socket cluster to the body.
3. Hold the main body just 1ST tier of metal frame and pass the electric and copper wires through body at center through the center hole. Place metal sphere on top of this and turn to tighten.
4. Shut off the main electrical supply from the main fuse box/circuit breaker.
5. Gently pull wiring down from ceiling junction box and allow to hang.
6. Open/ unscrew the bush just below the canopy.
7. Remove mounting spider from the canopy by unscrewing the collar. Let the Canopy fall down.
8. Then you will find Mounting Spider/ Centre nipple/ bush in correct position.
9. Align holes in mounting spider with holes in junction box and attach with two mounting screws. Secure screws with a Phillips screwdriver.
10. Pull down the ceiling/ junction box wire through the centre nipple for connection.
11. Insert the two stripped wires and the braided copper ground wire through the nipple assembly, locknut and mounting spider. Using the wire nuts, attach the ribbed wire to the white "neutral" house wire and the un-ribbed wire to the black "hot" house wire. Secure the wire nuts with black electrical tape. Connect the braided copper ground wire to the green house wire. It is imperative that the outlet box in your home be properly grounded.
DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
12. Then push the canopy to the mounting spider & attach the 4 screw back& also screw the bush back to complete the electrical assembly.
13. Insert 1Type A 60W, bulbs (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
14. Restore power to junction box and test fixture.

CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.