

D0061-6:6PCS
D0061-8:8PCS

② arms

③ screwing locknuts
D0061-6:6PCS
D0061-8:8PCS

④ connector 2PCS

⑤ cylinder tube
D0061-6:6PCS
D0061-8:8PCS

⑥ canopy 1PCS

⑦ locknuts 2PCS

⑧ hanging chain 1PCS

⑨ center lampbody 1PCS

⑩ metal box 1PCS

⑪ lock nut 1PCS

X 1PCS bracket

X 1PCS connector

X 3PCS bolt screw

X 3PCS cap connector

X 3PCS expansion anchor PVC

X 3PCS screws

1. Install the arms 2 on the round plate 1 by lock nut and teeth lock washer 3.

1. Pull the orange operating handle A to open the inlet hole, insert the wire B.
2. Press the operating handle A to finish wiring.
(Note: one inlet hole can put 2 or 3 wires inside)

2. Connect all the wires by parallel with connectors 4 (all live line-L use one connector, and neutral Line-N use another connector).

3. Install the round cover 5 on the plate 1 with lock nut 6.

4. Connect the fixture 1 and the canopy 10 by chain 9, after that let the wire go through the chain 9 and the canopy 10.

5. Install the bracket 12 on the junction box with expansion anchor PVC and screw.
6. Connect the wire with connector 13 to your home line.
7. Install the fixture on the bracket with cap nuts 14.
8. Put the cylinder tube 15 on the lamp holder and after that install the bulbs 16.

D0061/6/8

Please read carefully before installation!!!

Note : Please make sure that the electricity is powered off during installation !

Only a professional electrician should install this kind of product !