
ASSEMBLY INSTRUCTION
N759P468943



WARNING



This product is NOT a Clothing Storage Unit (CSU).
DO NOT use it for clothing storage.
Improper use may cause furniture tipover.


Before Installation

Important-Please read these instructions fully before starting assembly


Thank you for purchasing this quality product.Be sure to check all packing materials carefully for small parts,which may have come loose inside the carton during shipment.Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below.Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person;this will make the assembly easier,and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area,small parts could choke if swallowed.·Please put all parts on a non-abrasive floor before assembly,and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


Cam Lock Assembly Instructions




Insert Cam Bolt into hole as shown in diagram A.




Make sure not to insert the Cam Bolt:
Too deep as shown in figure B as this will cause the Cam Lock to be misaligned and unable to interlock properly.




Also avoid inserting the Cam Bolt too close to the surface of the hole as shown in figure C,as this will cause the Cam Lock to be too loose,and not interlock properly.




Connect the panels together.




















Insert the Cam Lock so the side opening fits over the head of the Cam Bolt.









To tighten the Cam Lock,turn it clockwise on half a turn with a flat screwdriver.
*Do not use an automatic screwdriver as it may bend or break if too much power is imposed.


5
6
4
3
8
7
2
1
9
14
15
10
11
16
13
12
x2

		
① x 1	② x 1	③ x 1
		
④ x 1	⑤ x 1	⑥ x 1
		
⑦ x 1	⑧ x 1	⑨ x 1
		
⑩ x 1	⑪ x 1	⑫ x 2

		
⑬ x 2	⑭ x 2	⑮ x 2
		
⑯ x 2		


					
Φ6x35mm	Φ15x12mm	Φ8x30mm	Φ5x25mm		M3.5x14mm
A x 28+2	B x 28+2	C x 20+2	D x 4	E x 2	F x 48+2
					
M4x14mm	M4x16mm	M6x60mm	M4x35mm		
G x 12+1	H x 4	I x 2	J x 24+2	K x 2	L x 4
					
Φ8x40mm					
M x 2	N x 4	O x 4			

Slides Must Be Separated Before Assembly.
After Separated, Set Aside Until Needed for Assembly.

Las diapositivas deben separarse antes del montaje.
Después de la separación,déjelo a un lado hasta que sea necesario.


Les glissières doivent être séparées avant l'assemblage.
Après la séparation,mettez de cŏté jusqu'au moment de l'assemblage.

Pay attention when connecting !
The sliding module must be at the front end.




STEP 1 : Extend Slide
Extender la diapositiva

STEP 2: Push Lever UP
Empujar hacia arriba
Lever le levier





Push lever for the left of drawer ,
press the lever for the right of drawer.





STEP 3: Remove Runner
Quitar el corredor
Enever le coureur


Step 1
















Φ6x35mm	M3.5x14mm	N x 4
A x 16	F x 12	


Step 2



Φ15x12mm	Φ8x30mm	M4x35mm
B x 2	C x 6	J x 8




Step 3




Φ8x30mm	M4x35mm
C x 4	J x 4


Step 4









Step 5





Step 6







Φ8x30mm

C x 5

Step 7









Φ15x12mm

B x 7

Step 8






E x 2



M4x14mm

G x 12

Step 9






Φ5x25mm


D x 4

Step 10




M3.5x14mm	M4x16mm	K x 2	L x 4
F x 8	H x 4		


Step 11




M3.5x14mm
F x 16

Step 12









To adjust the vertical height.

Loosen the four screws "c" on both hinges.Two of them are usually in slotted holes which allows you to adjust up or down by a few mm.Then tighten back up.



To adjust depth.


Loosen screw "a" and adjust door,if the door can not be adjusted,please loosen screw "b" ,then try again. Tighten screw "a" and "b" .





To adjust side ways.

Turning the screw "b" on BOTH hinges on each door.


Step 13









Step 14







Step 15




x2






M3.5x14mm	O
F x 12	O x 4


Step 16



Step 17





Wall



Step 18

Wall








Φ8x40mm

M x 2


Step 19

Wall





Step 20



Step 21

